

# INNER TUBE & OUTER TUBE WRENCHES İÇ TÜP VE DIŞ TÜP ANAHTARLARI



	DESCRIPTION	AÇIKLAMA
1	AWL INNER-TUBE WRENCH	AWL İÇ TÜP ANAHTARI
2	BWL INNER-TUBE WRENCH	BWL İÇ TÜP ANAHTARI
3	NWL INNER-TUBE WRENCH	NWL İÇ TÜP ANAHTARI
4	HWL INNER-TUBE WRENCH	HWL İÇ TÜP ANAHTARI
5	PWL INNER-TUBE WRENCH	PWL İÇ TÜP ANAHTARI
6	AWL OUTER-TUBE WRENCH	AWL DIŞ TÜP ANAHTARI
7	BWL OUTER-TUBE WRENCH	BWL DIŞ TÜP ANAHTARI
8	NWL OUTER-TUBE WRENCH	NWL DIŞ TÜP ANAHTARI
9	HWL OUTER-TUBE WRENCH	HWL DIŞ TÜP ANAHTARI
10	PWL OUTER-TUBE WRENCH	PWL DIŞ TÜP ANAHTARI

